




# imix®

## Color + Timer Settings



FamousNamesProducts.com



### Changing The Colors Of The Lights

- 1 • Press and hold the button for a second or so, until **imix** flashes orange.
- 2 • Release the button.  
• You can now choose your own color or range of colors.  
• **imix** will cycle slowly through all colors.
- 3 **Select a custom range of colors**  
• Press button to choose the starting color of the range.
- 4 • Press button again to choose the end color of range.  
• Pressing the button in quick succession will choose a single color.  
• Holding the button down for more than 2 seconds will switch the lights off completely.

### Setting The Timer



- 1 • Unplug the USB cable.
- 2 • Press and hold the button.
- 3 • While pressing the button, plug in the USB cable.
- 4 • Wait for a few seconds, until **imix** flashes blue.
- 5 • Release the button.  
• You can now set the timer.
- 6 • Press the button in rapid succession for the number of mixing minutes you want.

*Example: pressing 6 times will set the timer for 6 minutes.*

### Reset To Factory Defaults



- 1 • Unplug the USB cable.
- 2 • Press and hold the button.
- 3 • While pressing the button, plug in the USB cable.
- 4 • When **imix** flashes orange, release the button.
- 5 • **imix** will flash green and is reset to it's default values  
• The colors during mixing will be the default blue/pink.  
• The timer will set to 5 minutes.

